



# Assembly Instructions

## Montageanleitung


### WT36ART-ST-EXTHW

#### Scan table extension







1x



4x




4x




40x

## SPARE PARTS




2x



2x





2x





5x



1





2




3




4




5




6





7




8





9



10



11



12

